



Spigot Boot Shim Addition

After you have installed the spigots according to the installation data sheet, you may need to install the 0.2mm shim between the spigot boot and the spigot on the opposing side from the lever (1) (2).

With help from another person, it is recommended that two people lift the Hercules glass panel up and slide it into the spigot boot.

Make sure the lever is out, not engaged (3).

Lower the Hercules glass panel into the spigot boot. Then close the lever (4). It will be difficult to close, and you may have to tap on the lever to fully close it (5).

If the glass has too much back and forth wiggle (6), have your associate push the Hercules glass panel away from you (7) while you slide the included custom fit anti-wiggle shim between the spigot boot and the spigot (8) until it bottoms out on the lever knob (9).

Included is a 0.8mm to 1.0mm shim and a 1.0mm to 1.5mm shim (10) in the wedge shim packet, we provide both shims so you can choose the one to best stabilize your glass panel.

Do this to both spigots. Installation is now complete.

Questions or Concerns

Contact ClearView Glass Railings
via email: John@CVGRailings.com

